

SNMP Web Pro Firmware Upgrade SOP

Step1: Turn off your computer's firewall. (optional)

NOTE: Your computer's firewall may block the update feature. If the update fails, be sure to turn off the firewall.

Step2 : Open SNMP Web Manager.

Step3 : Select the FTP server IP address. Refer to Diagram 1-1

NOTE: If applying upgrade for SNMP Web Server in LAN, FTP server IP address will be IP address of current PC in LAN. If applying upgrade for SNMP Web Server in specific networking, FTP server IP address will be IP address of current PC in Internet.




Diagram 1-1

Step4: Click "Browse" button to choose program file. Refer to Diagram 1-2.

NOTE: Program file will be named *.s19




Diagram 1-2

Step5 : Click “Upgrade” button to execute upgrade action.

Refer to Diagram 1-3.

NOTE: Need password, default 12345678.




Diagram 1-3

Step6 : When upgrade is complete, you may check the message in output window. Refer to Diagram 1-4.




Diagram 1-4